



VEBKO ONLINE HELP

Advanced Settings of “Report” Part 2

Category	tester
Section	AMT Sequencer Module
Language	English
Generated	2026-10-18

In "Margin Setting" section, it is possible to set all four margins of the text. In "Document Setting" section, by checking "Insert page number", you can insert page numbers on report pages. Also, by checking "Insert page break before main heading", every "HEADING" of the report is added to the beginning of every new page.




Figure 1




Figure 2

By selecting "Fit width to max length data" in "Page Size" section, size of the tables in the report is adjusted according to the page size while by selecting "Fix width", the page size remains fixed. If size of the table is larger than the page, some parts of the table goes beyond the page boundary.

In "Header/Footer setting", by checking "Header", "Header text" field appears which enables you to enter your desired text. Also in "Header height" section, you can specify your desired height for the "Header".




Figure 3

By clicking on "Logo" and opening "Import logo for report" window, you can insert a picture or the logo of the company in the "Header" of the report.

By checking "Footer", "Footer text" field appears which enables you to enter your desired text. Also in "Footer height" section, you can specify your desired height for the "Footer".

By checking "Show persons sign" and selecting "Setting", "Persons sign" window opens where you can add up to four signs to your report. By clicking on "Add persons sign" and clicking on "Signature" and selecting "Signature" you can add a "Signature" to your report. In "Title" and "Value" sections, title and name of the person are entered respectively.




Figure 4

In "Title" of the "Setting" section, you can enter a general title for all four signatures and add a box for every signature by checking "Show border in report". Also, in "Repeat mode" section, by selecting "Show in all pages" the entered signatures are displayed in all pages. But, by selecting "Show in last page", these signatures are displayed only in the last page.

In "Extra setting" section and in "Tested by", "Approved by", "Company", and "Comment" fields, you can enter the name of the performer of the test, the supervisor, and the company as well as comments respectively. Note that to show these items in the output report, other than checking their options in this section, you need to check their options in the tree diagram under abstract branch as well.




Figure 5

By selecting "Browse custom", you can display specific information of the "Xrio" file in the report by checking their corresponding option. For example, to display "Name plate" and "Location", you should check these options from the "Test object" tree diagram of the "Device" section in "Browse custom" and "Xrio block report setting" page so that the intended information is specifically displayed in the report.




Figure 6

[jg1]Advanced_settings_of_Report_part2